

2022 CHEVROLET CORVETTE SERVICE MANUAL

- **SEARCH**

1. **Power and Signal Distribution**

2. **Wire and Connector Repair**

3. **Repair Instructions**

- 4.

Tyco/AMP Connectors (SIR)

Special Tools

- *EL-38125* 550 Terminal Release Tool Kit
- *EL-38125* 580 Terminal Release Tool Kit
- *J-38125* 11A Terminal Release Tool
- *J-38125-215A* Terminal Release Tool

For equivalent regional tools, refer to Special Tools.

Removal Procedure

1.
Click here for full size
2. Using your thumbs press down and slide the red CPA away from the connector lever.
3.
Click here for full size
4. Using your thumb press down on the locking tab and move the lever to the released position.
5.
Click here for full size
6. Using terminal tool J-38125-11A or equivalent, release the wire dress cover locking tabs.
7.
Click here for full size
8. Pivot connector wire dress cover while removing from the connector body.
9.
Click here for full size
10. Using terminal tool J-38125-11A or equivalent, remove the TPA by lifting straight off the connector body.
11.
Click here for full size
12. Using terminal release tool J-38125-215A, place the tip of the tool on the outside edge next to the terminal and depress the lock tab and remove the rear of the connector body.

Terminal Repair Procedure

Use the appropriate terminal and crimper in order to replace the terminal.