

2022 CHEVROLET CORVETTE SERVICE MANUAL

- **SEARCH**

1. **Roof**

2. **Folding Top**

3. **Description and Operation**

- 4.

Folding Top and Folding Top Stowage Compartment Lid Operation

Warning:

When the folding top or folding top stowage compartment lid is opening or closing, personal injury may occur by the parts in motion. Ensure all individuals involved maintain a safe distance from these parts while operating to avoid any personal injury or vehicle damage.

Warning:

Components under the folding top stowage compartment lid, close to the engine, can get hot from running the engine. To help avoid the risk of burning unprotected skin, never touch these components until they have cooled, and always use a glove or towel to avoid direct skin contact.

Caution:

Follow these guidelines when operating the folding top or damage can occur:

- Remove all items from the roof, trunk lid, or folding top stowage compartment lid before operating.
- Remove all objects that may contact the folding top when it is operated.
- Do not leave the vehicle with the folding top open.
- Do not exceed 50 km/h (31 mph) until the folding top has completely closed or opened.
- Do not open or close the folding top while driving in high wind conditions.
- Do not operate the folding top multiple times in a short period of time without starting the engine to avoid draining the vehicle battery.
- Only store the vehicle with the folding top fully closed.

Opening the Folding Top “Driver Door Switch”

1. Note:

If the folding top operation is stopped before completion, the top will temporarily hold its position. Over time, the folding top stowage compartment lid may drift to a near closed position.

2. Ensure the folding top and folding top stowage compartment lid are clear of any objects.
3. The trunk must be closed.
4. Start the vehicle or place it in ACC/ACCESSORY.
5. When possible, operate the folding top when the vehicle is stopped. The folding top can be operated while driving below 50 km/h (31 mph) and will stop if that speed is exceeded. The folding top operation will take approximately 17 seconds. Make sure the folding top operation can be completed before that speed is reached.
6. [Click here for full size](#)
7. Press and hold . The windows will automatically lower.
8. After the convertible top is completely open, a chime sounds and a Driver Information Center (DIC) message displays. Release the switch.

If the radio is on, the sound may be muted for a brief time to automatically adjust the audio after the folding top is opened.

Opening the Folding Top “Remote Key”

1. Make sure the vehicle is in P (Park).
2. The trunk must be closed.

3. Keep visual contact with the vehicle. Press and release on the remote key and then quickly press and hold .
4. Hold until the folding top is completely opened and the exterior lamps flash. A chime will sound.

If the folding top stops before it has completely opened, press and then press again.

If the folding top still stops before it is completely open:

- Move closer to the vehicle.
- Hold until the operation is complete.
- Press and then again. Interference from other remote keys or devices may interrupt the operation.

If the top still does not open, use the convertible top switch in the vehicle. The convertible top cannot be closed using the remote key. Refer to the Remote Keyless Entry (RKE) System Operation in the owners manual.

Closing the Folding Top

1. Make sure the sunshade mirror covers are closed and the sunshades are stored in the center mount position.
2. Ensure the folding top and folding top stowage compartment lid are clear of any objects.
3. The trunk must be closed.
4. Start the vehicle or place it in ACC/ACCESSORY.
5. When possible, operate the folding top when the vehicle is stopped. The folding top can be operated while driving below 50 km/h (31 mph) and will stop if that speed is exceeded. The folding top operation will take approximately 17 seconds. Make sure the folding top operation can be completed before that speed is reached.
6. [Click here for full size](#)
7. Pull and hold on the driver door switch. The windows will automatically lower.
8. After the folding top is completely closed, a chime sounds and a DIC message displays. Release the switch. Raise the windows if needed. If the switch is held after the chime sounds, the windows will start to raise.

If the radio is on, the sound may be muted for a brief time to automatically adjust the audio after the folding top is closed.

Opening the Folding Top Stowage Compartment Lid “ Engine Access

1. Make sure the vehicle is in P (Park).
2. Ensure the folding top stowage compartment lid is clear of any objects.
3. The trunk and folding top must be closed.
4. Keep visual contact with the vehicle. Press and release on the remote key and then quickly press and hold on the remote key. The turn signals will flash once.
5. [Click here for full size](#)
6. Hold until the folding top stowage compartment lid completely opened. A DIC message will display, and the turn signals will flash once.

In the event the folding top stowage compartment lid is partially open, the motion of the tonneau cover will be in the opposite direction upon reactivation.

Closing the Folding Top Stowage Compartment Lid “ Engine Access

1. Make sure the vehicle is off.
2. Remove all objects from the folding top stowage compartment lid.
3. The trunk and folding top must be closed.
4. Keep visual contact with the vehicle. Press and release on the remote key and then quickly press and hold on the remote key.
5. [Click here for full size](#)
6. Hold until the folding top stowage compartment lid is completely closed. A DIC message will display, and the turn signals will flash once.

mcx30.com