

2022 CHEVROLET CORVETTE SERVICE MANUAL

- **SEARCH**

1. **Safety and Security**

2. **Seat Belts**

3. **Repair Instructions**

- 4.

Front Seat Belt Buckle Replacement



[Click here for full size](#)
Front Seat Removal and Installation

Fastener Caution.

Procedure

1. Remove the front seat belt buckle bolt.
2. If a NEW threaded component is being installed, loosen the adhesive using a metal pick or similar tool before proceeding. If threaded component is reused, prepare the threaded component using the following steps:
 1. Remove any loose cured adhesive from the external threads of the component using a lint free cloth.
 2. Thread the cleaned component into the internal mating threads and remove to loosen trapped cured adhesive.
 3. Apply thread locking adhesive to the external threads of the component.
- 3.

Adhesives, Fluids, Lubricants, and Sealers

- Ensure there are no gaps in the thread locking adhesive once applied to the component.

Tighten

45 N-m (33 lb ft)

Callout	Component Name
Preliminary Procedure	
1	Front Seat Belt Buckle Bolt Caution: Refer to
2	Front Seat Belt Buckle Procedure 1. Reposition the seat cushion cover as necessary to access the electrical connector. 2. Disconnect the electrical connector. 3. During installation, route the wiring harness around the outside and over top of the buckle in order to prevent wiring harness damage.

mcx30.com