

2022 CHEVROLET CORVETTE SERVICE MANUAL

- SEARCH

- 1. Seats
- 2. Seat Hardware, Trim, and Upholstery
- 3. Repair Instructions
- 4.

Front Seat Removal and Installation



Click here for full size
SIR Warning

Preliminary Procedures

- 1. Disable the SIR system

SIR Disabling and Enabling

- Disconnect the seat belt from the tensioner.

Front Seat Belt Retractor Replacement

Fastener Caution.

Procedure

Adjust the seat to gain access to the nuts.

Tighten

45 N-m (33 lb ft)

SIR Disabling and Enabling

Callout	Component Name

Callout	Component Name
Warning:	
Refer to	
1	Driver or Passenger Seat Nut [4x] Caution: Refer to
2	Front Seat Procedure 1. Disconnect the electrical connectors. 2. With the aid of an assistant, remove the front seat. 3. Enable the SIR System.

mcx30.com