

2022 CHEVROLET CORVETTE SERVICE MANUAL

- **SEARCH**

1. **Body Systems**

2. **Fixed and Moveable Windows**

3. **Repair Instructions**

- 4.

Rear Sliding Window Motor Replacement

Click here for full size

Rear Sliding Window Motor Cover Replacement

Fastener Caution.

Procedure

1. If NEW threaded components are being installed, loosen the adhesive using a metal pick or similar tool before proceeding. If threaded components are reused, prepare the threaded components using the following steps:
2.
 1. Remove any loose cured adhesive from the external threads of the components using a lint free cloth.
 2. Thread the cleaned components into the internal mating threads and remove to loosen trapped cured adhesive.
 3. Apply thread locking adhesive to the external threads of the components.

Adhesives, Fluids, Lubricants, and Sealers

- Ensure there are no gaps in the thread locking adhesive once applied to the component.

Tighten

5>N-m (44 lb in)

Callout	Component Name
Preliminary Procedure	
1	Rear Sliding Window Motor Bolt [2x] Caution: Refer to
2	Rear Sliding Window Motor Procedure Disconnect the electrical connector.