

2022 CHEVROLET CORVETTE SERVICE MANUAL

- SEARCH

1. Body Systems
2. Fixed and Moveable Windows
3. Repair Instructions
- 4.

Windshield Replacement

Removal Procedure

Warning:

When working with any type of glass or sheet metal with exposed or rough edges, wear approved safety glasses and gloves in order to reduce the chance of personal injury.

Warning:

If a window is cracked but still intact, crisscross the window with masking tape in order to reduce the risk of damage or personal injury.

Note:

Use a urethane adhesive systems which meet GM Specification GMW 15672.

1. Windshield Multifunction Sensor Mount Bracket Cover >>> Remove - Windshield Multifunction Sensor Mount Bracket Cover Replacement

2. Note:

It is not necessary to remove the components from the bracket. Leave the components on the bracket.

3. Remove the windshield bracket from the windshield.

4. Warning:

If broken glass falls into the defroster outlets, it can be blown into the passenger compartment and cause personal injury.

5. Cover to protect the following parts from broken glass:

- 6.

- Upper Dash Pad
- The defroster outlets and A/C outlets
- The seats and carpeting

7. Apply a double layer of masking tape around the perimeter of the painted surfaces.
8. Remove both body side upper front appliques. Body Side Upper Front Applique Replacement
9. Air Inlet Grille Panel >>> Remove - Air Inlet Grille Panel Replacement



10. [Click here for full size](#)
11. Using a suitable tool, carefully cut the lace and urethane adhesive bead around the window (1).
12. [Click here for full size](#)
13. Remove the windshield (1) and locating pins (2) from the vehicle.
14.
 - Leave a base of urethane on the pinchweld flange.
 - The only suitable lubrication is clear water.
15. Transfer components as necessary.

Installation Procedure

1. [Click here for full size](#)
2. Windshield (1) >> Install - Adhesive Installation of Windshields
3. [Click here for full size](#)
4. Using a plastic trim tool (1), insert along the top of the windshield (2) and tuck foam seal under the windshield.
5. Install the windshield bracket to the windshield.
6. Windshield Multifunction Sensor Mount Bracket Cover >>> Install - Windshield Multifunction Sensor Mount Bracket Cover Replacement
7. Air Inlet Grille Panel >> Install - Air Inlet Grille Panel Replacement
8. Install both body side upper front appliques. Body Side Upper Front Applique Replacement
9. Remove the double layer of masking tape around the perimeter of the painted surfaces.
10. Remove any remaining adhesive residue with a 50/50 mixture by volume of isopropyl alcohol and clean drinkable water. Wipe the surface dry with a clean lint-free towel.