

2022 CHEVROLET CORVETTE SERVICE MANUAL

- [SEARCH](#)

1. [Body Systems](#)
2. [Vehicle Access](#)
3. [Repair Instructions](#)
- 4.

Auxiliary Hood Latch Release Switch Replacement

Removal Procedure

1. [Click here for full size](#)
2. Rear End Trim Finish Panel Retainer (1) >> Release [2x]
3. Front Trim Finish Compartment Lamp Bezel (2) >> Remove
4. Disconnect the electrical connector.
5. [Click here for full size](#)
6. Using a suitable plastic trim tool, release the retaining tabs.
7. Auxiliary Hood Latch Release Switch (1) >> Remove

Installation Procedure

1. [Click here for full size](#)
2. Auxiliary Hood Latch Release Switch (1) >> Install
3. [Click here for full size](#)
4. Connect the electrical connector.
5. Front Trim Finish Compartment Lamp Bezel (2) >> Install (1)
6. Rear End Trim Finish Panel Retainer (1) >> Install [2x]