

2022 CHEVROLET CORVETTE SERVICE MANUAL

- **SEARCH**

1. **Brakes**
2. **Disc Brakes**
3. **Repair Instructions**
- 4.

Front Brake Shield Replacement (J55)

Warning:


The battery must be disconnected to prevent the brake master cylinder from pressurizing the hydraulic system during its automated self diagnostic tests that can possibly occur when a door is opened or the key transmitter is activated. Failure to follow this precaution may cause personal injury.

Warning:

Brake Dust Warning


Removal Procedure

1. Disconnect the battery negative cable. Battery Negative Cable Disconnection and Connection
2. Raise and support the vehicle. Lifting and Jacking the Vehicle
3. Remove the tire and wheel assembly. Tire and Wheel Removal and Installation
4. Front Brake Rotor >> Remove - Front Brake Rotor Replacement



5.
Click here for full size
6. Front Brake Shield Bolt (2) >> Remove [2x]
7. Front Brake Shield (1) >> Remove

Installation Procedure



1. [Click here for full size](#)
2. Front Brake Shield (1) >> Install
3. Caution:
Fastener Caution
4. Front Brake Shield Bolt (2) >> Install and tighten [2x]9 N-m (80 lb in)
5. Front Brake Rotor >> Install - Front Brake Rotor Replacement
6. Install the tire and wheel assembly. Tire and Wheel Removal and Installation
7. Connect the battery negative cable. Battery Negative Cable Disconnection and Connection