

2022 CHEVROLET CORVETTE SERVICE MANUAL

- SEARCH

1. Driver Information and Entertainment

2. Displays and Gauges

3. Specifications

- 4.

Ambient Air Temperature Sensor Resistance

Temperature		Ambient Air Temp Sensor Resistance (Min)	Ambient Air Temp Sensor Resistance (Max)
°F	°C	(kΩ)	(kΩ)
100.4	38	1.6	1.8
98.6	37	1.7	1.9
96.8	36	1.8	2.0
95.0	35	1.8	2.1
93.2	34	1.9	2.2
91.4	33	2.0	2.3
89.6	32	2.1	2.4
87.8	31	2.2	2.5
86.0	30	2.3	2.6
84.2	29	2.4	2.7
82.4	28	2.5	2.8
80.6	27	2.6	2.9
78.8	26	2.7	3.0
77	25	2.8	3.2
75.2	24	2.9	3.3
73.4	23	3.1	3.5
71.6	22	3.2	3.6
69.8	21	3.4	3.8
68.0	20	3.5	4.0
66.2	19	3.7	4.2
64.4	18	3.9	4.4
62.6	17	4.0	4.6
60.8	16	4.2	4.8
59.0	15	4.4	5.0
57.2	14	4.6	5.2
55.4	13	4.9	5.5
53.6	12	5.1	5.8
51.8	11	5.4	6.0
50.0	10	5.6	6.3