

2022 CHEVROLET CORVETTE SERVICE MANUAL

- **SEARCH**

1. **Engine/Propulsion**

2. **Engine Controls and Fuel - 6.2L (LT2)**

3. **Repair Instructions**

- 4.

Air Cleaner Outlet Duct Replacement (Convertible)

Removal Procedure

1. Air Cleaner Assembly >> Remove - Air Cleaner Assembly Replacement
2. Click here for full size
3. Positive Crankcase Ventilation Tube (1>) >> Disconnect - Plastic Collar Quick Connect Fitting Service
4. Air Cleaner Outlet Duct Clamp (2>) >> Loosen
5. Air Cleaner Outlet Duct (3>) >> Remove

Installation Procedure

1. Click here for full size
2. Air Cleaner Outlet Duct (3>) >> Install
3. Caution:
Refer to Fastener Caution.
4. Air Cleaner Outlet Duct Clamp (2>) >> Tighten 3.5N-m (31 lb in)
5. Positive Crankcase Ventilation Tube (1>) >> Connect - Plastic Collar Quick Connect Fitting Service
6. Air Cleaner Assembly >> Install - Air Cleaner Assembly Replacement