

2022 CHEVROLET CORVETTE SERVICE MANUAL

- **SEARCH**

1. [Engine/Propulsion](#)
2. [Engine Controls and Fuel - 6.2L \(LT2\)](#)
3. [Repair Instructions](#)
- 4.

Auxiliary Fuel Tank Shield Replacement - Left Side (Convertible)

Removal Procedure

1. Fuel Tank - Left Side >> Remove - Fuel Tank Replacement - Left Side
2. [Click here for full size](#)
3. Auxiliary Fuel Tank Shield (1>) >> Remove

Installation Procedure

1. [Click here for full size](#)
2. Auxiliary Fuel Tank Shield (1>) >> Install
3. Fuel Tank - Left Side >> Install - Fuel Tank Replacement - Left Side

mcx30.com