

2022 CHEVROLET CORVETTE SERVICE MANUAL


- SEARCH

1. Engine/Propulsion
2. Engine Controls and Fuel - 6.2L (LT2)
3. Repair Instructions
- 4.

Auxiliary Fuel Tank Shield Replacement - Left Side (Coupe)

Removal Procedure


1. Exhaust Manifold - Left Side >> Remove - Exhaust Manifold Replacement - Left Side
2. Note:
Do not remove the engine to reposition the panel.
3. Dash Panel Outer Insulator >> Reposition - Dash Panel Outer Insulator Replacement



4.
Click here for full size
5. Auxiliary Fuel Tank Shield Bolt (1>) >> Remove [8>x]
6. Click here for full size
7. Auxiliary Fuel Tank Shield (1>) >> Remove

Installation Procedure

1. Click here for full size
2. Auxiliary Fuel Tank Shield (1>) >> Install



3. [Click here for full size](#)
4. **Caution:**
Refer to Fastener Caution.
5. Auxiliary Fuel Tank Shield Bolt (1>) >> Install and tighten [8>x]9>N-m (80 lb in)
6. Dash Panel Outer Insulator >> Install - Dash Panel Outer Insulator Replacement
7. Exhaust Manifold - Left Side >> Install - Exhaust Manifold Replacement - Left Side