

2022 CHEVROLET CORVETTE SERVICE MANUAL


- **SEARCH**

1. **Engine/Propulsion**
2. **Engine Controls and Fuel - 6.2L (LT2)**
3. **Repair Instructions**
- 4.

Auxiliary Fuel Tank Shield Replacement - Right Side


Removal Procedure

1. Fuel Tank &“ Right Side >> Remove - Fuel Tank Replacement - Right Side



2.
Click here for full size
3. Auxiliary Fuel Tank Shield (1>) >> Remove

Installation Procedure



1.
[Click here for full size](#)
2. Auxiliary Fuel Tank Shield (1>) >> Install
3. Fuel Tank "Right Side" >> Install - Fuel Tank Replacement - Right Side