

2022 CHEVROLET CORVETTE SERVICE MANUAL

- SEARCH

1. Engine/Propulsion
2. Engine Controls and Fuel - 6.2L (LT2)
3. Repair Instructions
- 4.

Fuel Sender Assembly Replacement

Special Tools

CH&A“52075&,Â Fuel Pump Lock Ring Wrench

Equivalent regional tools: Special Tools

Removal Procedure


Warning:

Refer to Diesel/Gasoline Vapors Warning.


Warning:

Refer to Safety Glasses Warning.

1. Fuel Tank - Right Side >> Remove - Fuel Tank Replacement - Right Side




2.
Click here for full size
3. Fuel Feed and Evaporative Emission Pipe (1>) >> Disconnect [2>x] - Plastic Collar Quick Connect Fitting Service




4.
[Click here for full size](#)

5. Fuel Sender Ring (1) >> Remove - CH&A"52075&,Â Fuel Pump Lock Ring Wrench(2)



6.
[Click here for full size](#)

7. Vent Pipe (1>) >> Disconnect [2>x] - Plastic Collar Quick Connect Fitting Service




8.
[Click here for full size](#)

9. Fuel Sender (1) >> Remove

10. Fuel Pump Seal (2) >> Remove and DISCARD


Installation Procedure



1.
[Click here for full size](#)


2. Fuel Pump Seal (2) >> Install NEW

3. Fuel Sender (1) >> Install




4.
[Click here for full size](#)

5. Vent Pipe (1>) >> Connect [2>x] - Plastic Collar Quick Connect Fitting Service



6.
[Click here for full size](#)

7. Fuel Sender Ring (1) >> Install - CH&A's 52075&A Fuel Pump Lock Ring Wrench(2)



8.

[Click here for full size](#)

9. Fuel Feed and Evaporative Emission Pipe (1>) >> Connect [2>x] - Plastic Collar Quick Connect Fitting Service

10. Fuel Tank - Right Side >> Install - Fuel Tank Replacement - Right Side