


# 2022 CHEVROLET CORVETTE SERVICE MANUAL

- SEARCH

- 1. Engine/Propulsion
- 2. Engine Controls and Fuel - 6.2L (LT2)
- 3. Repair Instructions
- 4.

## Fuel Tank Pressure Sensor Replacement



Click here for full size  
Diesel/Gasoline Vapors Warning.

Warning:

Refer to

Safety Glasses Warning.

Preliminary Procedures

- 1. Disconnect the battery negative cable.

Battery Negative Cable Disconnection and Connection

- 

Auxiliary Fuel Tank Shield Replacement - Left Side

| Callout  | Component Name |
|----------|----------------|
| Warning: |                |
| Refer to |                |
|          |                |

| Callout | Component Name                       |
|---------|--------------------------------------|
| 1       | Fuel Tank Pressure Sensor            |
|         | Procedure                            |
|         | Disconnect the electrical connector. |

mcx30.com