

2022 CHEVROLET CORVETTE SERVICE MANUAL


- **SEARCH**

1. Engine/Propulsion
2. **Engine Heating and Cooling**
3. Repair Instructions
- 4.


Radiator Inlet Hose Replacement - Water Pump Outlet Pipe to Transmission Cooler (Coupe)

Removal Procedure

1. Open the liftgate.
2. Drain the cooling system. [Cooling System Draining and Filling](#)




3. [Click here for full size](#)
4. Radiator Inlet Hose Clamp (1) Disengage - [Hose Clamp Replacement Guidelines - Spring Type](#)
5. Radiator Inlet Hose (2) @ Water Pump Outlet Pipe >> Remove




6. [Click here for full size](#)
7. Radiator Inlet Hose Retainer (1) >> Disengage
8. Radiator Inlet Hose (2) @ Transmission Cooler >> Remove
9. Radiator Inlet Hose (2) >> Remove

Installation Procedure



1. [Click here for full size](#)

2. Radiator Inlet Hose (2) @ Transmission Cooler >> Install
3. Radiator Inlet Hose Retainer (1) >> Engage



4. [Click here for full size](#)
5. Radiator Inlet Hose (2) @ Water Pump Outlet Pipe >> Install
6. Radiator Inlet Hose Clamp (1) Engage - Hose Clamp Replacement Guidelines - Spring Type
7. Fill the cooling system to the proper level. [Cooling System Draining and Filling](#)
8. Start the engine and check for coolant leaks.
9. Close the liftgate.