

2022 CHEVROLET CORVETTE SERVICE MANUAL


- **SEARCH**

1. [Engine/Propulsion](#)
2. [Engine Heating and Cooling](#)
3. [Repair Instructions](#)
- 4.


Radiator Inlet Pipe Replacement (Without E60)

Removal Procedure


1. Drain the cooling system. Cooling System Draining and Filling




2. [Click here for full size](#)
3. Front Compartment Insulator (6) >> Remove - Front Compartment Insulator Replacement
4. Battery Distribution Engine Compartment Fuse Block >> Remove - Battery Distribution Engine Compartment Fuse Block Replacement



5. [Click here for full size](#)
6. Radiator Inlet Hose (2) @ Radiator Inlet Pipe >>> Remove - Radiator Inlet Hose Replacement - Radiator Inlet Pipe to A/C Tube
7. Radiator Outlet Hose @ Radiator Inlet Pipe >>> Remove - Radiator Outlet Hose Replacement - Radiator Inlet Pipe to A/C Tube




8. [Click here for full size](#)
9. Radiator Inlet Hose (2) @ Radiator Inlet Pipe >>> Remove - Radiator Inlet Hose Replacement - Front Left Side




10.
[Click here for full size](#)

11. Radiator Inlet Hose (2) @ Radiator Inlet Pipe >> Remove - Radiator Inlet Hose Replacement - Front Right Side




12.
[Click here for full size](#)

13. Auxiliary Radiator Outlet Hose (2) @ Radiator Inlet Pipe >> Remove - Auxiliary Radiator Outlet Hose Replacement - Left Side Radiator




14.
[Click here for full size](#)

15. Auxiliary Radiator Outlet Hose (2) @ Radiator Inlet Pipe >> Remove - Auxiliary Radiator Outlet Hose Replacement - Right Side Radiator




16.
[Click here for full size](#)

17. Radiator Inlet Hose Bracket Bolt (1) >> Remove [2x]




18. [Click here for full size](#)
19. Radiator Inlet Hose Bracket Bolt (1) >> Remove
20. Radiator Inlet Pipe (2) >>> Remove

Installation Procedure




1. [Click here for full size](#)
2. Radiator Inlet Pipe (2) >>> Install
3. Caution:
Refer to Fastener Caution.
4. Radiator Inlet Hose Bracket Bolt (1) >> Install and tighten 9 N-m (80 lb in)




5.
[Click here for full size](#)

6. Radiator Inlet Hose Bracket Bolt (1) >> Install and tighten [2x]9 N-m (80 lb in)




7.
[Click here for full size](#)

8. Auxiliary Radiator Outlet Hose (2) @ Radiator Inlet Pipe >> Install - Auxiliary Radiator Outlet Hose Replacement - Right Side Radiator




9.
[Click here for full size](#)

10. Auxiliary Radiator Outlet Hose (2) @ Radiator Inlet Pipe >> Install - Auxiliary Radiator Outlet Hose Replacement - Left Side Radiator



11.
[Click here for full size](#)


12. Radiator Inlet Hose (2) @ Radiator Inlet Pipe >> Install - Radiator Inlet Hose Replacement - Front Right Side



13.
[Click here for full size](#)

14. Radiator Inlet Hose (2) @ Radiator Inlet Pipe >> Install - Radiator Inlet Hose Replacement - Front Left Side


15. Radiator Outlet Hose @ Radiator Inlet Pipe >> Install - Radiator Outlet Hose Replacement - Radiator Inlet Pipe to A/C Tube



16.
[Click here for full size](#)

17. Radiator Inlet Hose (2) @ Radiator Inlet Pipe >> Install - Radiator Inlet Hose Replacement - Radiator Inlet Pipe to A/C Tube

18. Battery Distribution Engine Compartment Fuse Block >> Install - Battery Distribution Engine Compartment Fuse Block Replacement



19.
Click here for full size
20. Front Compartment Insulator (6) >> Install - Front Compartment Insulator Replacement
21. Fill the cooling system to the proper level. Cooling System Draining and Filling
22. Start the engine and check for coolant leaks.