

2022 CHEVROLET CORVETTE SERVICE MANUAL


- **SEARCH**

1. **Engine/Propulsion**
2. **Engine Heating and Cooling**
3. **Repair Instructions**
- 4.

Radiator Outlet Hose Replacement - Water Pump Outlet Pipe to Transmission Cooler (Coupe)


Removal Procedure

1. Open the rear compartment lid.
2. Drain the cooling system. [Cooling System Draining and Filling](#)



3. [Click here for full size](#)
4. Radiator Outlet Hose Retainer (1) >>> Disengage
5. Radiator Outlet Hose Clamp (2) Disengage - [Hose Clamp Replacement Guidelines - Spring Type](#)
6. Radiator Outlet Hose (3) >>> Remove

Installation Procedure



1. [Click here for full size](#)
2. Radiator Outlet Hose (3) >> Install
3. Radiator Outlet Hose Clamp (2) Engage - [Hose Clamp Replacement Guidelines - Spring Type](#)
4. Radiator Outlet Hose Retainer (1) >> Engage
5. Fill the cooling system to the proper level. [Cooling System Draining and Filling](#)
6. Start the engine and check for coolant leaks.
7. Close the rear compartment lid.