

ELECTRICAL

Wiring Systems and Power Management - Component Locator - Front of Vehicle/Engine Compartment Component Views - Canyon, Colorado

FRONT OF VEHICLE/ENGINE COMPARTMENT COMPONENT VIEWS

FRONT OF VEHICLE/ENGINE COMPARTMENT COMPONENT VIEWS




Fig. 1: Front of Vehicle Components

Courtesy of GENERAL MOTORS COMPANY

Items

- A9B Outside Rearview Mirror - Passenger
- E13RA Headlamp Assembly - Right
- E13LA Headlamp Assembly - Left
- A9A Outside Rearview Mirror - Driver
- E4J Park Lamp - Left Front **E4J Park Lamp - Left Front (X88)**
- E4G Headlamp - Left Low Beam **E4H Headlamp - Right Low Beam**
- E4E Headlamp - Left High Beam **E4E Headlamp - Left High Beam**
- E4N Park/Turn Signal Lamp - Left **E4N Park/Turn Signal Lamp - Left**

Items

E29LF Fog Lamp - Left Front (T3U) E29LF Fog Lamp - Left Front (T3U)
 B9 Ambient Air Temperature Sensor B9 Ambient Air Temperature Sensor
 E29RF Fog Lamp - Right Front (T3U) E29RF Fog Lamp - Right Front (T3U)
 E4P Park/Turn Signal Lamp - Right E4P Park/Turn Signal Lamp - Right
 E4F Headlamp - Right High Beam E4F Headlamp - Right High Beam
 E4H Headlamp - Right Low Beam E4H Headlamp - Right Low Beam
 E4K Park Lamp - Right Front E4J Park Lamp - Right Front (X88)

FRONT OF VEHICLE COMPONENTS (GMC/Z88)




Fig. 2: Front of Vehicle Components (GMC/Z88)

Courtesy of GENERAL MOTORS COMPANY

Items

A9B Outside Rearview Mirror - Passenger
 E13RA Headlamp Assembly - Right
 E13LA Headlamp Assembly - Left
 A9A Outside Rearview Mirror - Driver
 E4AC Park/Daytime Running Lamp - Left (Z88)
 E4N Park/Turn Signal Lamp - Left E4N Park/Turn Signal Lamp - Left

Items

E4AL Park/Daytime Running Lamp - Left Lower (Z88)
 E4G Headlamp - Left Low Beam [E4H Headlamp - Right Low Beam](#)
 E29LF Fog Lamp - Left Front (T3U) [E29LF Fog Lamp - Left Front \(T3U\)](#)
 E4E Headlamp - Left High Beam [E4E Headlamp - Left High Beam](#)
 B9 Ambient Air Temperature Sensor [B9 Ambient Air Temperature Sensor](#)
 E4F Headlamp - Right High Beam [E4F Headlamp - Right High Beam](#)
 E29RF Fog Lamp - Right Front (T3U) [E29RF Fog Lamp - Right Front \(T3U\)](#)
 E4H Headlamp - Right Low Beam [E4H Headlamp - Right Low Beam](#)
 E4AM Park/Daytime Running Lamp - Right Lower (Z88)
 E4P Park/Turn Signal Lamp - Right [E4P Park/Turn Signal Lamp - Right](#)
 E4AD Park/Daytime Running Lamp - Right (Z88)

LEFT SIDE OF ENGINE COMPARTMENT COMPONENTS (1 OF 2)




Fig. 3: Left Side of Engine Compartment Components (1 of 2)

Courtesy of GENERAL MOTORS COMPANY

Items

M75 Windshield Wiper Motor [M75 Windshield Wiper Motor](#)
 B19B Brake Booster Vacuum Sensor [B19B Brake Booster Vacuum Sensor](#)

Items

B20 Brake Fluid Level Switch [B20 Brake Fluid Level Switch \(LCV/LFX\)](#) [B20 Brake Fluid Level Switch \(LWN\)](#)

C1 Battery [C1 Battery](#)

X50D Fuse Block - Battery [X50D Fuse Block - Battery X1](#) [X50D Fuse Block - Battery X2](#) [X50D Fuse Block - Battery X3](#) [X50D Fuse Block - Battery X4 \(LFX\)](#) [X50D Fuse Block - Battery X5](#) [X50D Fuse Block - Battery X6](#) [X50D Fuse Block - Battery X7](#)

R10 Cooling Fan Resistor [R10 Cooling Fan Resistor \(LWN\)](#)

X50A Fuse Block - Underhood [X50A Fuse Block - Underhood X1](#) [X50A Fuse Block - Underhood X2](#) [X50A Fuse Block - Underhood X3](#) [X50A Fuse Block - Underhood X4](#) [X50A Fuse Block - Underhood X5](#)

B18 Battery Current Sensor [B18 Battery Current Sensor](#)

LEFT FRONT OF ENGINE COMPARTMENT COMPONENTS




Fig. 4: Left Front of Engine Compartment Components

Courtesy of GENERAL MOTORS COMPANY

Items

G24 Windshield Washer Pump [G24 Windshield Washer Pump](#)

B55 Hood Ajar Switch (UTJ) [B55 Hood Ajar Switch \(UTJ\)](#)

B59L Front Impact Sensor - Left [B59L Front Impact Sensor - Left](#)

FRONT OF ENGINE COMPARTMENT COMPONENTS




Fig. 5: Front of Engine Compartment Components

Courtesy of GENERAL MOTORS COMPANY

Items

M96 Active Grille Air Shutter Actuator M96 Active Grill Air Shutter Actuator (LCV) M96 Active Grill Air Shutter Actuator (LFX)

RADIATOR ASSEMBLY COMPONENTS




Fig. 6: Radiator Assembly Components
 Courtesy of GENERAL MOTORS COMPANY

Items

K22 Cooling Fan Control Module [K22 Cooling Fan Control Module \(LCV/LFX\)](#)

B203 Engine Coolant Radiator Temperature Sensor (LCV) [B203 Engine Coolant Radiator Temperature Sensor \(LCV\)](#)

RIGHT FRONT OF ENGINE COMPARTMENT COMPONENTS




Fig. 7: Right Front of Engine Compartment Components

Courtesy of GENERAL MOTORS COMPANY

Items

B59R Front Impact Sensor - Right **B59R Front Impact Sensor - Right**

P13 Horn Assembly **P13 Horn Assembly**

RIGHT REAR OF ENGINE COMPARTMENT COMPONENTS




Fig. 8: Right Rear of Engine Compartment Components

Courtesy of GENERAL MOTORS COMPANY

Items

K20 Engine Control Module K20 Engine Control Module X1 (LCV) K20 Engine Control Module X1 (LFX) K20 Engine Control Module X1 (LWN) K20 Engine Control Module X2 (LCV) K20 Engine Control Module X2 (LFX) K20 Engine Control Module X2 (LWN) K20 Engine Control Module X3 (LCV) K20 Engine Control Module X3 (LFX) K20 Engine Control Module X3 (LWN)