

ELECTRICAL

Wiring Systems and Power Management - Component Locator - Passenger Compartment/Roof
Component Views - Canyon, Colorado

PASSENGER COMPARTMENT/ROOF COMPONENT VIEWS

DRIVER SEAT BACK COMPONENTS




Fig. 1: Driver Seat Back Components

Courtesy of GENERAL MOTORS COMPANY

Items

M52D Seat Lumbar Support Horizontal Motor - Driver (AL9) [M52D Seat Lumbar Support Horizontal Motor - Driver](#)

DRIVER SEAT COMPONENTS




Fig. 2: Driver Seat Components
 Courtesy of GENERAL MOTORS COMPANY

Items	
M51D Seat Horizontal Motor - Driver	<u>M51D Seat Horizontal Motor - Driver</u>
M55D Seat Rear Vertical Motor - Driver	<u>M55D Seat Rear Vertical Motor - Driver</u>
E14A Seat Heating Element - Driver Back (KA1)	<u>E14A Seat Heating Element - Driver Back (KA1)</u>
F106D Seat Side Air Bag - Driver	<u>F106D Seat Side Air Bag - Driver</u>
F113D Seat Belt Anchor Pretensioner - Driver	<u>F113D Seat Belt Anchor Pretensioner - Driver</u>
S64D Seat Adjuster Switch - Driver	<u>S64D Seat Adjuster Switch - Driver X1 S64D Seat Adjuster Switch - Driver X2</u>
E14B Seat Heating Element - Driver Cushion (KA1)	<u>E14B Seat Heating Element - Driver Cushion (KA1)</u>
B88D Seat Belt Switch - Driver	<u>B88D Seat Belt Switch - Driver</u>

PASSENGER SEAT BACK COMPONENTS




Fig. 3: Passenger Seat Back Components
Courtesy of GENERAL MOTORS COMPANY

Items

M52P Seat Lumbar Support Horizontal Motor - Passenger (AAQ) [M52D Seat Lumbar Support Horizontal Motor - Passenger](#)

PASSENGER SEAT COMPONENTS




Fig. 4: Passenger Seat Components
 Courtesy of GENERAL MOTORS COMPANY

Items

M55P Seat Rear Vertical Motor - Passenger (AAQ)	<u>M55P Seat Rear Vertical Motor - Passenger</u>
K85 Passenger Presence Module (AL0)	<u>K85 Passenger Presence Module</u>
M51P Seat Horizontal Motor - Passenger (AAQ)	<u>M51P Seat Horizontal Motor - Passenger</u>
K29 Seat Heating Control Module (KA1)	<u>K29 Seat Heating Control Module X1 (KA1)</u> <u>K29 Seat Heating Control Module X2 (KA1)</u>
E14C Seat Heating Element - Passenger Back (KA1)	<u>E14C Seat Heating Element - Passenger Back (KA1)</u>
B88P Seat Belt Switch - Passenger	<u>B88P Seat Belt Switch - Passenger</u>
E14D Seat Heating Element - Passenger Cushion (KA1)	<u>E14D Seat Heating Element - Passenger Cushion (KA1)</u>
S64P Seat Adjuster Switch - Passenger (AAQ)	<u>S64P Seat Adjuster Switch - Passenger X1</u> <u>S64P Seat Adjuster Switch - Passenger X2</u>
F113P Seat Belt Anchor Pretensioner - Passenger	<u>F113P Seat Belt Anchor Pretensioner - Passenger</u>
F106P Seat Side Air Bag - Passenger	<u>F106P Seat Side Air Bag - Passenger</u>
E14D Seat Heating Element - Passenger Cushion (KA1)	<u>E14D Seat Heating Element - Passenger Cushion (KA1)</u>

GER COMPONENTS (CREW CAB)




Fig. 5: Left Passenger Components (Crew Cab)

Courtesy of GENERAL MOTORS COMPANY

Items

B63LR Side Impact Sensor - Left Rear **B63LR Side Impact Sensor - Left Rear**

F105L Roof Rail Air Bag - Left **F105L Roof Rail Air Bag - Left (Crew Cab)** **F105L Roof Rail Air Bag - Left (Extended Cab)**

B80 Park Brake Switch **B80 Park Brake Switch**

K9 Body Control Module **K9 Body Control Module X1** **K9 Body Control Module X2** **K9 Body Control Module X3** **K9 Body Control Module X7**

K36 Inflatable Restraint Sensing and Diagnostic Module **K36 Inflatable Restraint Sensing and Diagnostic Module X1**

F112D Seat Belt Retractor Pretensioner - Driver **F112D Seat Belt Retractor Pretensioner - Driver (Crew Cab)** **F112D Seat Belt Retractor Pretensioner - Driver (Extended Cab)**

LEFT PASSENGER COMPONENTS (EXTENDED CAB)




Fig. 6: Left Passenger Components (Extended Cab)

Courtesy of GENERAL MOTORS COMPANY

Items

B63LR Side Impact Sensor - Left Rear [B63LR Side Impact Sensor - Left Rear](#)

F105L Roof Rail Air Bag - Left [F105L Roof Rail Air Bag - Left \(Crew Cab\)](#) [F105L Roof Rail Air Bag - Left \(Extended Cab\)](#)

K9 Body Control Module [K9 Body Control Module X1](#) [K9 Body Control Module X2](#) [K9 Body Control Module X3](#) [K9 Body Control Module X4](#) [K9 Body Control Module X5](#) [K9 Body Control Module X6](#) [K9 Body Control Module X7](#)

K36 Inflatable Restraint Sensing and Diagnostic Module [K36 Inflatable Restraint Sensing and Diagnostic Module X1](#)

RIGHT PASSENGER COMPONENTS (CREW CAB)




Fig. 7: Right Passenger Components (Crew Cab)
 Courtesy of GENERAL MOTORS COMPANY

Items
K73 Telematics Communication Interface Control Module (UE1) <u>K73 Telematics Communication Interface Control Module X1 (UE1)</u> <u>K73 Telematics Communication Interface Control Module X2 (UE1)</u> <u>K73 Telematics Communication Interface Control Module X5</u>
F105R Roof Rail Air Bag - Right <u>F105R Roof Rail Air Bag - Right (Crew Cab)</u> <u>F105R Roof Rail Air Bag - Right (Extended Cab)</u>
B63RR Side Impact Sensor - Right Rear <u>B63RR Side Impact Sensor - Right Rear</u>
F112P Seat Belt Retractor Pretensioner - Passenger <u>F112P Seat Belt Retractor Pretensioner - Passenger (Crew Cab)</u> <u>F112P Seat Belt Retractor Pretensioner - Passenger (Extended Cab)</u>
X51A Fuse Block - Instrument Panel <u>X51A Fuse Block - Instrument Panel X1</u> <u>X51A Fuse Block - Instrument Panel X2</u> <u>X51A Fuse Block - Instrument Panel X3 ((LCV/LFX)+N8D)</u> <u>X51A Fuse Block - Instrument Panel X3 ((LCV/LFX)-N8D)</u> <u>X51A Fuse Block - Instrument Panel X3 (LWN)</u>
K69 Transfer Case Control Module (NQ6/NQ7) <u>K69 Transfer Case Control Module X1 (NQ6/NQ7)</u> <u>K69 Transfer Case Control Module X2 (NQ6/NQ7)</u>
T15 Navigation Antenna Signal Splitter (IO6) <u>T15 Navigation Antenna Signal Splitter X1</u> <u>T15 Navigation Antenna Signal Splitter X2</u> <u>T15 Navigation Antenna Signal Splitter X3</u>

RIGHT PASSENGER COMPONENTS (EXTENDED CAB)




Fig. 8: Right Passenger Components (Extended Cab)

Courtesy of GENERAL MOTORS COMPANY

Items
K73 Telematics Communication Interface Control Module (UE1) <u>K73 Telematics Communication Interface Control Module X1 (UE1)</u> <u>K73 Telematics Communication Interface Control Module X2 (UE1)</u> <u>K73 Telematics Communication Interface Control Module X5</u> <u>K73 Telematics Communication Interface Control Module X7</u>
F105R Roof Rail Air Bag - Right <u>F105R Roof Rail Air Bag - Right (Crew Cab)</u> <u>F105R Roof Rail Air Bag - Right (Extended Cab)</u>
B63RR Side Impact Sensor - Right Rear <u>B63RR Side Impact Sensor - Right Rear</u>
X51A Fuse Block - Instrument Panel <u>X51A Fuse Block - Instrument Panel X1</u> <u>X51A Fuse Block - Instrument Panel X2</u> <u>X51A Fuse Block - Instrument Panel X3 ((LCV/LFX)+N8D)</u> <u>X51A Fuse Block - Instrument Panel X3 ((LCV/LFX)-N8D)</u> <u>X51A Fuse Block - Instrument Panel X3 (LWN)</u>
K69 Transfer Case Control Module (NQ6/NQ7) <u>K69 Transfer Case Control Module X1 (NQ6/NQ7)</u> <u>K69 Transfer Case Control Module X2 (NQ6/NQ7)</u>
T15 Navigation Antenna Signal Splitter (IO6) <u>T15 Navigation Antenna Signal Splitter X1</u> <u>T15 Navigation Antenna Signal Splitter X2</u> <u>T15 Navigation Antenna Signal Splitter X3</u>

PASSENGER COMPARTMENT/ROOF COMPONENT VIEWS




Fig. 9: Headliner Components (Crew Cab)
 Courtesy of GENERAL MOTORS COMPANY

Items

K109 Frontview Camera Module (UEU/UFL) [K109 Frontview Camera Module \(UEU/UFL\)](#)
 B160 Windshield Temperature and Inside Moisture Sensor (C68) [B160 Windshield Temperature and Inside Moisture Sensor \(C68\)](#)
 K77 Remote Control Door Lock Receiver [K77 Remote Control Door Lock Receiver](#)
 E37R Dome/Reading Lamps - Rear [E37R Dome/Reading Lamps - Rear](#)
 E37F Dome/Reading Lamps - Front (C74) [E37F Dome/Reading Lamps - Front \(C74\)](#)
 P14 Passenger Air Bag Disabled Indicator [P14 Passenger Air Bag Disabled Indicator](#)
 E31R Sunshade Mirror Lamp - Right (D6I) [E31R Sunshade Mirror Lamp - Right \(D6I\)](#)
 A10 Inside Rearview Mirror [A10 Inside Rearview Mirror](#)
 E31L Sunshade Mirror Lamp - Left (D6I) [E31L Sunshade Mirror Lamp - Left \(D6I\)](#)
 B24 Cellular Phone Microphone (UE1) [B24 Cellular Phone Microphone \(UE1\)](#)

HEADLINER COMPONENTS (EXTENDED CAB)




Fig. 10: Headliner Components (Extended Cab)
 Courtesy of GENERAL MOTORS COMPANY

Items

- K109 Frontview Camera Module (UEU/UFL) [K109 Frontview Camera Module \(UEU/UFL\)](#)
 B160 Windshield Temperature and Inside Moisture Sensor (C68) [B160 Windshield Temperature and Inside Moisture Sensor \(C68\)](#)
 K77 Remote Control Door Lock Receiver [K77 Remote Control Door Lock Receiver](#)
 E37R Dome/Reading Lamps - Rear [E37R Dome/Reading Lamps - Rear](#)
 E37F Dome/Reading Lamps - Front (C74) [E37F Dome/Reading Lamps - Front \(C74\)](#)
 E31R Sunshade Mirror Lamp - Right (D6I) [E31R Sunshade Mirror Lamp - Right \(D6I\)](#)
 P14 Passenger Air Bag Disabled Indicator [P14 Passenger Air Bag Disabled Indicator](#)
 A10 Inside Rearview Mirror [A10 Inside Rearview Mirror](#)
 E31L Sunshade Mirror Lamp - Left (D6I) [E31L Sunshade Mirror Lamp - Left \(D6I\)](#)
 B24 Cellular Phone Microphone (UE1) [B24 Cellular Phone Microphone \(UE1\)](#)