

2006 Chevrolet Equinox LS

CABIN AIR FILTERS Passenger Compartment Air Filter - Equinox & Torrent

CABIN AIR FILTERS

Passenger Compartment Air Filter - Equinox & Torrent

REMOVAL & INSTALLATION

NOTE: Manufacturer's terminology for this filter is passenger compartment air filter.

CABIN AIR FILTER

Removal & Installation

1. Remove the push pins from the rear of the right hand air inlet panel. See **Fig. 1**.




Fig. 1: View Of Right Hand Air Inlet Panel Push Pins (Rear)
Courtesy of GENERAL MOTORS CORP.

2. Open the hood. Remove the push pins from the top and forward edge of the right hand air inlet panel. See **Fig. 2**.




Fig. 2: View Of Right Hand Air Inlet Panel Push Pins (Front)
Courtesy of GENERAL MOTORS CORP.

3. Remove the right hand air inlet panel. See **Fig. 3**.




Fig. 3: Removing/Installing Right Hand Air Inlet Panel
Courtesy of GENERAL MOTORS CORP.

4. Remove the filter from the filter housing by depressing the release tab at the inboard edge of the filter housing. See **Fig. 4**.




Fig. 4: Removing/Installing Passenger Compartment Air Filter
Courtesy of GENERAL MOTORS CORP.

5. Remove the filter from the vehicle. To install filter, reverse removal procedure.