

CONV ID

C1-27 L-GN	C5-25 BN
C2-25 WH	C6-25 PK
C3-25 L-BU	C7-28 GY
C4-25 BK	

Wiper/Washer Schematic

Body Control Module (BCM)

Legend: L (Left), O (Output), C (Control), D (Driver), E (Electrical), C (Control)

Wiring Diagram Details:

- Door Locks:** Driver Door Lock, Passenger Door Lock, Driver Door Lock, Passenger Door Lock.
- Door Latch Switches:** Driver Door Latch Switch, Passenger Door Latch Switch, Driver Door Latch Switch, Passenger Door Latch Switch.
- Door Latch Drivers:** Driver Door Latch Driver, Passenger Door Latch Driver, Driver Door Latch Driver, Passenger Door Latch Driver.
- Wiper/Washer:** Wiper/Washer Schematic.
- Wiring:** The diagram shows the electrical connections for the BCM, including the wiper/washer system and the door latch system. The BCM is connected to the wiper/washer system via a 1303 PK/BK 0.5 wire. The BCM is also connected to the door latch system via a 1303 PK/BK 0.5 wire. The door latch system is connected to the door latch drivers via a 1303 PK/BK 0.5 wire. The door latch drivers are connected to the door latch switches via a 1303 PK/BK 0.5 wire. The door latch switches are connected to the door locks via a 1303 PK/BK 0.5 wire.

G311

9/10/2011