

2010 ELECTRICAL

Wiring Systems and Power Management - Component Locator - Equinox & Terrain

DOOR COMPONENT VIEWS




Fig. 1: Identifying Driver Door Components
Courtesy of GENERAL MOTORS CORP.

Callout	Component Name
1	A23D Door Latch Assembly - Driver
2	A9A Outside Rearview Mirror - Driver
3	E1C Accent Lamp - Driver Door Handle (LTZ or SLT)
4	K96L Mirror Control Module - Left (LTZ or SLT)
5	S52S Outside Rearview Mirror Switch
6	P19G Speaker - Left Front
7	M74D Window Motor - Driver
8	B63LF Side Impact Sensor - Left Front
9	S79D Window Switch - Driver
10	E1D Accent Lamp - Driver Door (LTZ or SLT)




Fig. 2: Identifying Passenger Door Components
Courtesy of GENERAL MOTORS CORP.

Callout	Component Name
1	A9B Outside Rearview Mirror - Passenger
2	E1M Accent Lamp - Passenger Door Handle (LTZ or SLT)
3	S79P Window Switch - Passenger
4	A23P Door Latch Assembly - Passenger
5	E1P Accent Lamp - Passenger Door (LTZ or SLT)
6	B63RF Side Impact Sensor - Right Front
7	M74P Window Motor - Passenger
8	P19U Speaker - Right Front




Fig. 3: Identifying Left Rear Door Components
Courtesy of GENERAL MOTORS CORP.

Callout	Component Name
1	A23LR Door Latch Assembly - Left Rear
2	S79LR Window Switch - Left Rear
3	M74LR Window Motor - Left Rear
4	P19K Speaker - Left Rear
5	B63LR Side Impact Sensor - Left Rear




Fig. 4: Identifying Right Rear Door Components
Courtesy of GENERAL MOTORS CORP.

Callout	Component Name
1	S79RR Window Switch - Right Rear
2	A23RR Door Latch Assembly - Right Rear
3	M74RR Window Motor - Right Rear
4	B63RR Side Impact Sensor - Right Rear
5	P19X Speaker - Right Rear