

2018 ELECTRICAL

Wiring Systems And Power Management - Component Locator - Front Of Vehicle/Engine Compartment Component Views - Equinox & Terrain

FRONT OF VEHICLE/ENGINE COMPARTMENT COMPONENT VIEWS

BEHIND THE FRONT FASCIA




Fig. 1: Behind The Front Fascia

Courtesy of GENERAL MOTORS COMPANY

Items
1. B306K Parking Assist Sensor - Side Left Front (UFQ) B306K Parking Assist Sensor - Side Left Front (UFQ)
2. B306A Parking Assist Sensor - Front Left Outer (UD5/UFQ) B306A Parking Assist Sensor - Front Left Outer (UD5/UFQ)
3. B174G Frontview Camera - Grille (UVH) B174G Frontview Camera - Grille (UVH)
4. B306C Parking Assist Sensor - Front Right Middle (UD5/UFQ) B306C Parking Assist Sensor - Front Right Middle (UD5/UFQ)
5. B306D Parking Assist Sensor - Front Right Outer (UD5/UFQ) B306D Parking Assist Sensor - Front Right Outer (UD5/UFQ)
6. B306L Parking Assist Sensor - Side Right Front (UFQ) B306L Parking Assist Sensor - Side Right Front (UFQ)
7. E29RF Fog Lamp - Right Front (T3U) E29RF Fog Lamp - Right Front (T3U)
8. B306B Parking Assist Sensor - Front Left Middle (UD5/UFQ) B306B Parking Assist Sensor - Front Left Middle (UD5/UFQ)
9. E29LF Fog Lamp - Left Front (T3U) E29LF Fog Lamp - Left Front (T3U)

FRONT OF THE ENGINE COMPARTMENT AND TRANSMISSION (MNH)




Fig. 2: Front Of The Engine Compartment And Transmission (MNH)

Courtesy of GENERAL MOTORS COMPANY

Items

1. K20 Engine Control Module K20 Engine Control Module X1 (LH7) K20 Engine Control Module X1 (LTG) K20 Engine Control Module X1 (LYX) K20 Engine Control Module X2 (LH7) K20 Engine Control Module X2 (LTG) K20 Engine Control Module X2 (LYX) K20 Engine Control Module X3 (LH7) K20 Engine Control Module X3 (LTG) K20 Engine Control Module X3 (LYX).
2. X50A Fuse Block - Underhood X50A Fuse Block - Underhood X1 X50A Fuse Block - Underhood X11 X50A Fuse Block - Underhood X2 X50A Fuse Block - Underhood X3 X50A Fuse Block - Underhood X5 (LH7) X50A Fuse Block - Underhood X6 X50A Fuse Block - Underhood X7 X50A Fuse Block - Underhood X8 X50A Fuse Block - Underhood X9
3. Q8 Control Solenoid Valve Assembly Q8 Control Solenoid Valve Assembly X1 (MHG/MNH/MNK) Q8 Control Solenoid Valve Assembly X2 (MHG/MNH/MNK) Q8 Control Solenoid Valve Assembly X3 (MHG/MNH/MNK) Q8 Control Solenoid Valve Assembly X4 (MHG/MNH/MNK).
4. B280 Automatic Transmission Accumulator Solenoid Valve (KL9) B280 Automatic Transmission Accumulator Solenoid Valve (KL9+MHG/MNH).

COOLING FAN




Fig. 3: Cooling Fan

Courtesy of GENERAL MOTORS COMPANY

Items

1. B1 A/C Refrigerant Pressure Sensor **B1 A/C Refrigerant Pressure Sensor**
2. B193A Charge Air Cooler Inlet Temperature Sensor (LH7) **B193A Charge Air Cooler Inlet Temperature Sensor (LH7)**
3. G10 Cooling Fan Motor **G10 Cooling Fan Motor**
4. B193B Charge Air Cooler Outlet Temperature Sensor (LH7) **B193B Charge Air Cooler Outlet Temperature Sensor (LH7)**
5. B111 Turbocharger Boost Sensor (LYX) **B111 Turbocharger Boost Sensor (LYX)**

LEFT FRONT OF THE VEHICLE




Fig. 4: Left Front Of The Vehicle

Courtesy of GENERAL MOTORS COMPANY

Items

1. B59R Front Impact Sensor - Right [B59R Front Impact Sensor - Right](#)
2. B55 Engine Hood Switch [B55 Engine Hood Switch](#)
3. B59L Front Impact Sensor - Left [B59L Front Impact Sensor - Left](#)
4. X50A Fuse Block - Underhood [X50A Fuse Block - Underhood X1 X50A Fuse Block - Underhood X11 X50A Fuse Block - Underhood X2 X50A Fuse Block - Underhood X3 X50A Fuse Block - Underhood X5 \(LH7\) X50A Fuse Block - Underhood X6 X50A Fuse Block - Underhood X7 X50A Fuse Block - Underhood X8 X50A Fuse Block - Underhood X9](#)
5. G19 Rear Window Washer Pump [G19 Rear Window Washer Pump](#)
6. G24 Windshield Washer Pump [G24 Windshield Washer Pump](#)
7. B118B Windshield Washer Fluid Level Switch [B118B Windshield Washer Fluid Level Switch](#)
8. B9 Ambient Air Temperature Sensor [B9 Ambient Air Temperature Sensor](#)
9. P13 Horn Assembly [P13 Horn Assembly](#)

LEFT SIDE OF THE ENGINE COMPARTMENT (1 OF 2)




Fig. 5: Left Side Of The Engine Compartment (1 Of 2)

Courtesy of GENERAL MOTORS COMPANY

Items

1. K20 Engine Control Module K20 Engine Control Module X1 (LH7) K20 Engine Control Module X1 (LTG) K20 Engine Control Module X1 (LYX) K20 Engine Control Module X2 (LH7) K20 Engine Control Module X2 (LTG) K20 Engine Control Module X2 (LYX) K20 Engine Control Module X3 (LH7) K20 Engine Control Module X3 (LTG) K20 Engine Control Module X3 (LYX).
2. X50A Fuse Block - Underhood X50A Fuse Block - Underhood X1 X50A Fuse Block - Underhood X11 X50A Fuse Block - Underhood X2 X50A Fuse Block - Underhood X3 X50A Fuse Block - Underhood X5 (LH7) X50A Fuse Block - Underhood X6 X50A Fuse Block - Underhood X7 X50A Fuse Block - Underhood X8 X50A Fuse Block - Underhood X9

LEFT SIDE OF THE ENGINE COMPARTMENT (2 OF 2)




Fig. 6: Left Side Of The Engine Compartment (2 Of 2)

Courtesy of GENERAL MOTORS COMPANY

Items

1. M75 Windshield Wiper Motor [M75 Windshield Wiper Motor](#)
2. B110 Battery Sensor Module (KL9) [B110 Battery Sensor Module X1 \(KL9\)](#) [B110 Battery Sensor Module X2 \(KL9\)](#)
3. C1 Battery
4. X50A Fuse Block - Underhood [X50A Fuse Block - Underhood X1](#) [X50A Fuse Block - Underhood X11](#) [X50A Fuse Block - Underhood X2](#) [X50A Fuse Block - Underhood X3](#) [X50A Fuse Block - Underhood X5 \(LH7\)](#) [X50A Fuse Block - Underhood X6](#) [X50A Fuse Block - Underhood X7](#) [X50A Fuse Block - Underhood X8](#) [X50A Fuse Block - Underhood X9](#)
5. X50D Fuse Block - Battery [X50D Fuse Block - Battery X1](#) [X50D Fuse Block - Battery X2](#) [X50D Fuse Block - Battery X3 \(KL9\)](#) [X50D Fuse Block - Battery X4 \(C32\)](#) [X50D Fuse Block - Battery X5](#) [X50D Fuse Block - Battery X6](#) [X50D Fuse Block - Battery X7](#) [X50D Fuse Block - Battery X8](#)
6. K17 Electronic Brake Control Module [K17 Electronic Brake Control Module](#)
7. B20 Brake Fluid Level Switch [B20 Brake Fluid Level Switch](#)
8. B19B Brake Booster Vacuum Sensor [B19B Brake Booster Vacuum Sensor](#)

REAR OF THE ENGINE COMPARTMENT/POWER STEERING CONTROL MODULE




Fig. 7: Rear Of The Engine Compartment/Power Steering Control Module
Courtesy of GENERAL MOTORS COMPANY

Items

1. K43 Power Steering Control Module **K43 Power Steering Control Module X1 K43 Power Steering Control Module X2**