


## 2018 ELECTRICAL

### Component Locator - Luggage Compartment/Rear of Vehicle Component Views

## LUGGAGE COMPARTMENT/REAR OF VEHICLE COMPONENT VIEWS


### LEFT REAR TRIM PANEL COMPONENTS



#### Items

1. P19AN Speaker - Left Rear Trim Panel (UQA) [P19AN Speaker - Left Rear Trim Panel](#)
2. X92RL USB Receptacle - Rear Compartment Left [X92RL USB Receptacle - Rear Compartment Left](#)


### RIGHT REAR TRIM PANEL COMPONENTS



#### Items

1. X92RR USB Receptacle - Rear Compartment Right [X92RR USB Receptacle - Rear Compartment Right](#)
2. P19AP Speaker - Right Rear Trim Panel (UQA) [P19AP Speaker - Right Rear Trim Panel](#)
3. S144B Folding Seat Control Switch - Rear Compartment 3rd Row (AS8) [S144B Folding Seat Control Switch - Rear Compartment 3rd Row \(AS8\)](#)
4. X80C Accessory Power Receptacle - Cargo [X80C Accessory Power Receptacle - Cargo \(W49\)](#) [X80C Accessory Power Receptacle - Cargo \(X88\)](#)


## REAR OF VEHICLE COMPONENTS (X88)



### Items

1. E5AK Tail Lamp - Left Outer [E5AK Tail Lamp - Left Outer \(W49\)](#), [E5AK Tail Lamp - Left Outer \(X88+CZ3\)](#), [E5AK Tail Lamp - Left Outer \(X88-CZ3\)](#)
2. E5G Tail Lamp - Left Inner [E5G Tail Lamp - Left Inner \(W49\)](#), [E5G Tail Lamp - Left Inner \(X88\)](#)
3. E5A Backup Lamp - Left
4. E18 Rear Defogger Grid [E18 Rear Defogger Grid X1](#), [E18 Rear Defogger Grid X2](#)
5. T2RR Antenna - Roof Rear [T2RR Antenna - Roof Rear X1](#), [T2RR Antenna - Roof Rear X2](#)
6. E6 Center High Mounted Stop Lamp [E6 Center High Mounted Stop Lamp](#)
7. E5B Backup Lamp - Right
8. E5H Tail Lamp - Right Inner [E5H Tail Lamp - Right Inner \(W49\)](#), [E5H Tail Lamp - Right Inner \(X88\)](#)
9. E5AL Tail Lamp - Right Outer [E5AL Tail Lamp - Right Outer \(W49\)](#), [E5AL Tail Lamp - Right Outer \(X88+CZ3\)](#), [E5AL Tail Lamp - Right Outer \(X88-CZ3\)](#)
10. E4RR Turn Signal Lamp - Right Rear
11. E5AN Stop/Turn Signal Lamp - Right
12. B306H Parking Assist Sensor - Rear Right Outer [B306H Parking Assist Sensor - Rear Right Outer](#)
13. B306G Parking Assist Sensor - Rear Right Middle [B306G Parking Assist Sensor - Rear Right Middle](#)
14. E7L License Plate Lamp - Left [E7L License Plate Lamp - Left \(-DRZ\)](#), [E7L License Plate Lamp - Left \(DRZ\)](#)
15. B87 Rearview Camera [B87 Rearview Camera X1 \(-DRZ\)](#), [B87 Rearview Camera X1 \(DRZ\)](#), [B87 Rearview Camera X2 \(DRZ\)](#)
16. E7R License Plate Lamp - Right [E7R License Plate Lamp - Right \(-DRZ\)](#), [E7R License Plate Lamp - Right \(DRZ\)](#)
17. S46B Liftgate Unlatch Switch [S46B Liftgate Unlatch Switch \(W49\)](#), [S46B Liftgate Unlatch Switch \(X88\)](#)
18. B306F Parking Assist Sensor - Rear Left Middle [B306F Parking Assist Sensor - Rear Left Middle](#)
19. X88 Trailer Connector [X88 Trailer Connector \(-V92\)](#), [X88 Trailer Connector \(V92\)](#)
20. B306E Parking Assist Sensor - Rear Left Outer [B306E Parking Assist Sensor - Rear Left Outer](#)
21. E5AM Stop/Turn Signal Lamp - Left
22. E4LR Turn Signal Lamp - Left Rear


## REAR OF VEHICLE COMPONENTS (W49)



### Items

1. E5AK Tail Lamp - Left Outer [E5AK Tail Lamp - Left Outer \(W49\)](#), [E5AK Tail Lamp - Left Outer \(X88+CZ3\)](#), [E5AK Tail Lamp - Left Outer \(X88-CZ3\)](#)
2. E18 Rear Defogger Grid [E18 Rear Defogger Grid X1](#), [E18 Rear Defogger Grid X2](#)
3. E6 Center High Mounted Stop Lamp [E6 Center High Mounted Stop Lamp](#)
4. T2RR Antenna - Roof Rear [T2RR Antenna - Roof Rear X1](#), [T2RR Antenna - Roof Rear X2](#)
5. E5AL Tail Lamp - Right Outer [E5AL Tail Lamp - Right Outer \(W49\)](#), [E5AL Tail Lamp - Right Outer \(X88+CZ3\)](#), [E5AL Tail Lamp - Right Outer \(X88-CZ3\)](#)
6. E4RR Turn Signal Lamp - Right Rear
7. E5AN Stop/Turn Signal Lamp - Right
8. E5B Backup Lamp - Right
9. E5H Tail Lamp - Right Inner [E5H Tail Lamp - Right Inner \(W49\)](#), [E5H Tail Lamp - Right Inner \(X88\)](#)
10. E7L License Plate Lamp - Left [E7L License Plate Lamp - Left \(-DRZ\)](#), [E7L License Plate Lamp - Left \(DRZ\)](#)
11. B87 Rearview Camera [B87 Rearview Camera X1 \(-DRZ\)](#), [B87 Rearview Camera X1 \(DRZ\)](#), [B87 Rearview Camera X2 \(DRZ\)](#)
12. S46B Liftgate Unlatch Switch [S46B Liftgate Unlatch Switch \(W49\)](#), [S46B Liftgate Unlatch Switch \(X88\)](#)
13. E7R License Plate Lamp - Right [E7R License Plate Lamp - Right \(-DRZ\)](#), [E7R License Plate Lamp - Right \(DRZ\)](#)
14. B306H Parking Assist Sensor - Rear Right Outer [B306H Parking Assist Sensor - Rear Right Outer](#)
15. B306G Parking Assist Sensor - Rear Right Middle [B306G Parking Assist Sensor - Rear Right Middle](#)
16. B306F Parking Assist Sensor - Rear Left Middle [B306F Parking Assist Sensor - Rear Left Middle](#)
17. B306E Parking Assist Sensor - Rear Left Outer [B306E Parking Assist Sensor - Rear Left Outer](#)
18. X88 Trailer Connector [X88 Trailer Connector \(-V92\)](#), [X88 Trailer Connector \(V92\)](#)
19. E5G Tail Lamp - Left Inner [E5G Tail Lamp - Left Inner \(W49\)](#), [E5G Tail Lamp - Left Inner \(X88\)](#)
20. E5A Backup Lamp - Left
21. E5AM Stop/Turn Signal Lamp - Left
22. E4LR Turn Signal Lamp - Left Rear


## REAR FASCIA COMPONENTS (X88)



### Items

1. B218R Side Object Sensor Module - Right (UKC) [B218R Side Object Sensor Module - Right \(UKC\)](#)
2. B306H Parking Assist Sensor - Rear Right Outer [B306H Parking Assist Sensor - Rear Right Outer](#)
3. B306G Parking Assist Sensor - Rear Right Middle [B306G Parking Assist Sensor - Rear Right Middle](#)
4. B306F Parking Assist Sensor - Rear Left Middle [B306F Parking Assist Sensor - Rear Left Middle](#)
5. K171 Hands-Free Liftgate Sensor Control Module (TC2) [K171 Hands-Free Liftgate Sensor Control Module X1 \(W49+TC2\)](#), [K171 Hands-Free Liftgate Sensor Control Module X1 \(X88+TC2\)](#), [K171 Hands-Free Liftgate Sensor Control Module X2 \(TC2\)](#), [K171 Hands-Free Liftgate Sensor Control Module X3 \(TC2\)](#)
6. B306E Parking Assist Sensor - Rear Left Outer [B306E Parking Assist Sensor - Rear Left Outer](#)
7. B218L Side Object Sensor Module - Left (UKC) [B218L Side Object Sensor Module - Left \(UKC\)](#)
8. E72 Hands-Free Liftgate Sensor Lamp (TC2) [E72 Hands-Free Liftgate Sensor Lamp \(TC2\)](#)
9. E29R Fog Lamp - Rear (T79) [E29R Fog Lamp - Rear \(\)](#)

## REAR FASCIA COMPONENTS (W49)



### Items

1. B306H Parking Assist Sensor - Rear Right Outer [B306H Parking Assist Sensor - Rear Right Outer](#)

## Items

2. B306G Parking Assist Sensor - Rear Right Middle [B306G Parking Assist Sensor - Rear Right Middle](#)
  3. B306F Parking Assist Sensor - Rear Left Middle [B306F Parking Assist Sensor - Rear Left Middle](#)
  4. K171 Hands-Free Liftgate Sensor Control Module (TC2) [K171 Hands-Free Liftgate Sensor Control Module X1 \(W49+TC2\)](#), [K171 Hands-Free Liftgate Sensor Control Module X1 \(X88+TC2\)](#), [K171 Hands-Free Liftgate Sensor Control Module X2 \(TC2\)](#), [K171 Hands-Free Liftgate Sensor Control Module X3 \(TC2\)](#)
  5. B306E Parking Assist Sensor - Rear Left Outer [B306E Parking Assist Sensor - Rear Left Outer](#)
  6. B218L Side Object Sensor Module - Left (UKC) [B218L Side Object Sensor Module - Left \(UKC\)](#)
  7. E72 Hands-Free Liftgate Sensor Lamp (TC2) [E72 Hands-Free Liftgate Sensor Lamp \(TC2\)](#)
  8. B218R Side Object Sensor Module - Right (UKC) [B218R Side Object Sensor Module - Right \(UKC\)](#)
- 

mcx30.com