


Item	Description
15	RH turn indicator
16	Lane assist system/forward collision warning display
17	Speedometer
18	Fuel gauge
19	Low fuel warning indicator
20	Lights on indicator
21	High beam indicator
22	Odometer display area
23	Compass
24	Main message center display area
25	PRNDL display
26	- Rotating RTT display area - BLIS® off - Charging system - Distance alert - Door ajar - Engine over-temperature - Hood ajar - Liftgate ajar - Low engine oil pressure - Low fuel - Low washer fluid - Overspeed warning (Gulf Cooperative Countries [GCC]) - Powertrain malfunction (wrench)
27	Auto high beam RTT indicator
28	SelectShift® display
29	Front fog lamp indicator
30	Temperature gauge
31	Auto stop/start indicator

High-Level IPC



High-Level IPC