


Parking Aid - Component Location

Component Location, Parking Aid - Audible



Item	Description
1	Front parking aid sensors (if equipped)
2	Right front active parking aid sensor (if equipped)
3	Parking aid disable switch (if equipped)
4	Front speakers (part of audio system)
5	Right rear active parking aid sensor (if equipped)
6	Rear parking aid sensors
7	Left rear active parking aid sensor (if equipped)
8	Rear speakers (part of audio system)
9	PAM (integrated into the BCM)
10	Left front active parking aid sensor (if equipped)