


Direct Current/Direct Current (DC/DC) Converter Control Module - System Operation and Component Description

System Diagram



Item	Description
1	High Current Battery Junction Box (BJB)
2	Ignition Relay
3	PCM
4	DCDC
5	BCM
6	Front Park Assist Camera
7	Rear Park Assist Camera
8	SODR
9	ACM
10	APIM
11	RTM
12	FCIM
13	GWM