


Passenger Door Window Control Switch

Removal


1. Remove the passenger door window control switch.
 1. Remove the passenger door window control switch and the bezel assembly.
 2. Disconnect the passenger door window control switch electrical connector.



2. **NOTE:** This step is only necessary when installing a new component.

Remove the passenger side front door window control switch.

1. Release the retaining tabs from the passenger side front door window control switch.
2. Remove the passenger side front door window control switch from the bezel.



Installation

1. To install, reverse the removal procedure.

