




5. Repeat steps 2-4 on the opposite side of the vehicle.
6. Install the parking brake actuator motors.
Refer to: Parking Brake Actuator Motor (206-05 Parking Brake and Actuation, Removal and Installation).

mcx30.com