


Steering Column - System Operation and Component Description

System Diagram



Item	Description
1	DDM
2	SCCM
3	Memory Set Switch
4	DSM
5	BCM
6	MS-CAN
7	HS2-CAN
8	Steering Column Control Switch
9	Steering Column Tilt Motor
10	Hall Effect Sensor
11	GWM
12	Steering Column Telescopic Motor
13	Hall Effect Sensor
14	HS1-CAN