


Evaporative Emissions - System Operation and Component Description

System Operation

Refer to the PC/ED manual section 1 Description and Operation.

System Diagram



Item	Description
1	RH valve cover
2	Air cleaner (ACL) outlet pipe-to-Throttle body
3	AWD vacuum solenoid assembly
4	LH valve cover
5	PCV valve
6	Brake booster
7	Intake manifold
8	EVAP canister purge valve
9	EVAP canister assembly
10	EVAP canister vent solenoid and dust separator assembly
11	Fuel tank
12	Fuel vent valve
13	Dual check valve
14	Turbocharger to CAC tube
15	Vapor ejector
16	Air Cleaner (ACL) outlet pipe