

Solenoid Operation Chart

Base Selector Lever Position	PCM Commanded Gear	SSA (1, 2, 3, 4, 5)	SSB (4, 6, R)	SSC (3, 7)	SSD (R, 1)	SSE (5, 6, 7, 8)	SSF (2, 8)
P	P	Off	Off	Off	On	Off	On
R	R	Off	On	Off	On	Off	Off
N	N	Off	Off	Off	On	Off	Off
D	1	On	Off	Off	Off	Off	Off
	2	On	Off	Off	Off	Off	On
	3	On	Off	On	Off	Off	Off
	4	On	On	Off	Off	Off	Off
	5	On	Off	Off	Off	On	Off
	6	Off	On	Off	Off	On	Off
	7	Off	Off	On	Off	On	Off
	8	Off	Off	Off	Off	On	On

Clutch Application Chart

Gear	Clutch A (1, 2, 3, 4, 5)	Clutch B (4, 6)	Clutch C (3, 7)	One-Way Clutch (1)	Electronic Selectable One-Way Clutch (SOWC) (1)	Clutch E (5, 6, 7, 8)	Clutch F (2, 8)
Park					H		H
Reverse		D			H		
1st Gear D	H			H			
2nd Gear D	H						H
3rd Gear D	H		H				
4th Gear D	H	D					
5th Gear D	H					D	
6th Gear D		D				D	
7th Gear D			H			D	
8th Gear D						D	H
1st Gear Manual	H				H		
Planetary Component	Output Sun	Reaction Sun	Overdrive Sun	Overdrive/Reaction Input Ring Gear	Input Ring/Reaction Carrier	Input Ring/Reaction Carrier	Overdrive Sun

- H = Holding
- D = Driven