


External Controls - Component Location



Item	Description
1	Downshift paddle switch
2	Upshift paddle switch
3	Transmission park by wire release cable (8F57)
4	Transmission park by wire release cable (8F35/8F40)
5	GSM