



Description and Operation

Climate Control System - Vehicles With: Dual Automatic Temperature Control (DATC) - Component Location



Item	Description
1	In-Vehicle Temperature & Humidity Sensor
2	Auto Lamp & Sunload Sensor
3	FCIM & HVAC Control Module



Item	Description
1	Driver Side Footwell Air Discharge Temperature Sensor
2	Heater Core
3	Evaporator Temperature Sensor
4	Driver Side Temperature Door Actuator