


Wireless Accessory Charging Module (WACM) - System Operation and Component Description

System Operation

System Diagram



Item	Description
1	APIM
2	BCM
3	ACM
4	WACM
5	GWM

Network Message Chart

APIM Module Network Input Messages

Broadcast Message	Originating Module	Message Purpose
WACM send signals	WACM	Contains the status of the WACM charging input to be used for FCIM display.