

Diagnosis and Testing

Wireless Accessory Charging Module (WACM)

Diagnostic Trouble Code (DTC) Chart

Diagnostics in this manual assume a certain skill level and knowledge of Ford-specific diagnostic practices.

REFER to: Diagnostic Methods (100-00 General Information, Description and Operation).

REFER to: Battery (414-01 Battery, Mounting and Cables, Diagnosis and Testing).

Diagnostic Trouble Code Chart

Module	DTC	Description	Action <i>New: hover over Pinpoint Test links to show title</i>
BCM	B1554:11	Wireless Accessory Charger Enable\Disable: Circuit short to ground	GO to Pinpoint Test A
BCM	B1554:13	Wireless Accessory Charger Enable\Disable: Circuit open	GO to Pinpoint Test A
WACM	U0140:00	Lost Communication With Body Control Module: No Sub Type Information	GO to Pinpoint Test D
WACM	U0184:00	Lost Communication With Radio: No Sub Type Information	GO to Pinpoint Test F
WACM	U0257:00	Lost Communication With Front Controls / Display Interface Module: No Sub Type Information	GO to Pinpoint Test E
WACM	U201A:51	Control Module Main Calibration Data: Not Programmed	GO to Pinpoint Test H
WACM	U2100:00	Initial Configuration Not Complete: No Sub Type Information	GO to Pinpoint Test H
WACM	U2101:00	Control Module Configuration Incompatible: No Sub Type Information	GO to Pinpoint Test H
WACM	U3000:41	Control Module: General Checksum	GO to Pinpoint Test G
WACM	U3000:42	Control Module: General Memory Failure	GO to Pinpoint Test G
WACM	U3000:49	Control Module: Internal Electronic Failure	GO to Pinpoint Test G
WACM	U3003:16	Battery Voltage: Circuit Voltage Below Threshold	GO to Pinpoint Test C
WACM	U3003:17	Battery Voltage: Circuit Voltage Above Threshold	GO to Pinpoint Test C

Symptom Chart(s)

Symptom Chart: WACM (Wireless Accessory Charging Module)

Diagnostics in this manual assume a certain skill level and knowledge of Ford-specific diagnostic practices.

REFER to: Diagnostic Methods (100-00 General Information, Description and Operation).

Condition	Possible Sources	Actions