




Vehicles equipped with police floor console

4. Remove the floor console.
Refer to: Floor Console (501-12 Instrument Panel and Console, Removal and Installation).

All vehicles

5. **NOTE:** One screw on each side.

Remove the screws.
Torque: 22 lb.in (2.5 Nm)



6. Release the clips and position the center dash lower trim panel out.