


Front Door Tweeter Speaker

Removal

NOTE: Removal steps in this procedure may contain installation details.

1. Remove the front door trim panel.
Refer to: Front Door Trim Panel (501-05 Interior Trim and Ornamentation, Removal and Installation).
2. Release the tabs and remove the front door tweeter speaker.



Installation

1. To install, reverse the removal procedure.


Instrument Panel Center Speaker

Special Tool(s) / General Equipment


Interior Trim Remover

Removal

1. Release the clips and remove the instrument panel center speaker grille.
Use the General Equipment: Interior Trim Remover



2. Remove the screws, disconnect the electrical connector and remove the instrument panel center speaker.



Installation

1. To install, reverse the removal procedure.