

Condition	Possible Sources	Actions
All courtesy lamps do not illuminate at any time - police vehicles only	Police Silent Mode is active	For police equipped vehicles, when Police Silent Mode is activated through the instrument cluster message center, the courtesy lamps will not illuminate. Courtesy lamps operation will return to normal when Police Silent Mode is deactivated. For more information on Police Silent Mode function, activation and deactivation, REFER to: Instrument Panel Cluster (IPC) - System Operation and Component Description (413-01 Instrumentation, Message Center and Warning Chimes, Description and Operation).
The courtesy lamps do not illuminate with a door open	Refer to the Pinpoint Test	GO to Pinpoint Test A
One or more interior courtesy lamps are inoperative	Refer to the Pinpoint Test	GO to Pinpoint Test B
The courtesy lamps do not illuminate with the liftgate open	Refer to the Pinpoint Test	GO to Pinpoint Test J
A puddle lamp is inoperative or always on	Refer to the Pinpoint Test	GO to Pinpoint Test G
All the courtesy lamps stay on continuously	Refer to the Pinpoint Test	GO to Pinpoint Test C
The interior courtesy lamps stay on continuously	Refer to the Pinpoint Test	GO to Pinpoint Test D
One or more demand lamps are inoperative	Refer to the Pinpoint Test	GO to Pinpoint Test E
The battery saver does not deactivate after time-out	Refer to the Pinpoint Test	GO to Pinpoint Test F
The ambient lighting is inoperative or always on	Refer to the Pinpoint Test	GO to Pinpoint Test H
One or more of the ambient lighting Light Emitting Diodes (LEDs) are inoperative or do not change color/intensity	Refer to the Pinpoint Test	GO to Pinpoint Test I

Pinpoint Tests

☐ [PINPOINT TEST A : THE COURTESY LAMPS DO NOT ILLUMINATE WITH A DOOR OPEN](#)

☐ [PINPOINT TEST B : ONE OR MORE INTERIOR COURTESY LAMPS ARE INOPERATIVE](#)

☐ [PINPOINT TEST C : ALL THE COURTESY LAMPS STAY ON CONTINUOUSLY](#)

☐ [PINPOINT TEST D : THE INTERIOR COURTESY LAMPS STAY ON CONTINUOUSLY](#)

☐ [PINPOINT TEST E : ONE OR MORE DEMAND LAMPS ARE INOPERATIVE](#)

☐ [PINPOINT TEST F : THE BATTERY SAVER DOES NOT DEACTIVATE AFTER TIME-OUT](#)

☐ [PINPOINT TEST G : A PUDDLE LAMP IS INOPERATIVE OR ALWAYS ON](#)

☐ [PINPOINT TEST H : THE AMBIENT LIGHTING IS INOPERATIVE OR ALWAYS ON](#)

☐ PINPOINT TEST I : ONE OR MORE OF THE AMBIENT LIGHTING LIGHT EMITTING DIODES (LEDS) ARE INOPERATIVE OR DO NOT CHANGE COLOR/INTENSITY

☐ PINPOINT TEST J : THE COURTESY LAMPS DO NOT ILLUMINATE WITH THE LIFTGATE OPEN

mcx30.com

18: Electrical Distribution

mcx30.com

418-00 Module Communications Network