





4. **WARNING: Be prepared to collect escaping fluids.**

Remove the front differential drain plug.



Filling

1. Install the front differential drain plug.
Torque: 30 lb.ft (40 Nm)