




Installation

1. To install, reverse the removal procedure.
2. Using the previous diagnostic scan tool session, carry out the PMI procedure for the RTM.
Refer to: Module Configuration - System Operation and Component Description (418-01 Module Configuration, Description and Operation).

mcx30.com