

Body Closures - Overview

Overview

The power liftgate feature allows power opening and closing of the liftgate using any of the following methods:

- The front power liftgate switch (located on the instrument panel).
 - The rear interior power liftgate switch (located on the bottom of the liftgate trim panel) (close only).
 - The liftgate release switch (located in upper portion of the liftgate handle cavity).
 - The power liftgate hands-free feature (if equipped).
 - The liftgate button on a RKE transmitter.
-

mcx30.com