


Passenger Door Window Control Switch

Special Tool(s) / General Equipment

Interior Trim Remover

Removal


1. Remove the passenger door window control switch bezel assembly.
 1. Release the locking tabs from the passenger door window control switch bezel assembly.
Use the General Equipment: Interior Trim Remover
 2. Disconnect the electrical connector and remove the passenger door window control switch bezel assembly.



2. **NOTE:** This step is only necessary when installing a new component.

Remove the passenger door window control switch from the bezel assembly.

1. Release the locking tabs from the passenger door window control switch.
2. Remove the passenger door window control switch from the bezel assembly.



Installation

1. To install, reverse the removal procedure.

