




mcx30.com



3. Remove the keyless entry rear antenna.
 1. Remove the keyless entry rear antenna nuts.
 2. Remove the keyless entry rear antenna.