


Steering Column - System Operation and Component Description

System Diagram



Item	Description
1	DDM
2	SCCM
3	Memory set switch
4	DSM
5	BCM
6	MS-CAN
7	HS-CAN2
8	Steering column control switch
9	Steering column tilt motor
10	Hall effect sensor
11	GWM
12	Steering column telescopic motor
13	Hall effect sensor
14	HS-CAN1