









3. Remove the floor crane and chain.







4. Remove Special Service Tool: 303-1529 Lift Eye, Engine.