





3. Remove the floor crane and chain,.



4. Remove Special Service Tool: 303-1245 Engine Lift Eye.