

SECTION 415-00C: Information and Entertainment Systems — 4.2-Inch (107 mm)
Display


REMOVAL AND INSTALLATION

2014 F-150 Workshop
Manual

Procedure revision date:
10/25/2013

Speaker — A-Pillar

NOTE: LH shown, RH similar.



Item	Part Number	Description
1	W701678-S	A-pillar speaker screws (2 required)
2	18978	A-pillar speaker

Removal and Installation

1. Remove the A-pillar trim panel. For additional information, refer to [Section 501-05](#).
2. Remove the 2 screws and the A-pillar speaker.
3. To install, reverse the removal procedure.

mcx30.com