


SECTION 415-00E: Information and Entertainment Systems — Sony® 8-Inch (203 mm) Touchscreen

REMOVAL AND INSTALLATION

2014 F-150 Workshop
Manual

Procedure revision date:
10/25/2013

Global Positioning System Module (GPSM)



Item	Part Number	Description
1	W707628-S	Global Positioning System Module (GPSM) screw
2	—	<u>GPSM</u> electrical connector (part of 14401)
3	10E893	<u>GPSM</u>

Removal and Installation

1. Remove the Front Display Interface Module (FDIM). For additional information, refer to [Front Display Interface Module \(FDIM\)](#) in this section.
2. Remove the screw and the Global Positioning System Module (GPSM).
 - Disconnect the electrical connector.
3. To install, reverse the removal procedure.

mcx30.com